

WY-50/WY-50 + Maintenance Manual

880020-01 Rev. B
January 1986

Wyse Technology Inc.
3471 N. First Street
San Jose, CA 95134-1803 U.S.A.

Printed in U.S.A.

3 TROUBLESHOOTING

INTRODUCTION

This terminal is easy to troubleshoot. Chapter 3 describes its self-test, diagnostics, and hardware problems. It also explains how to fix problems at the board level.

POWER-ON SELF-TEST

Note--Self-test returns the terminal to default values.

The power-on self-test checks the terminal's RAM, CPU, and EAROM. The RAM test is a Write/Read test that checks all 4K of RAM. The CPU test checks 128 bytes of RAM in the CPU as well as the data and address lines. The EAROM test calculates the EAROM's checksum and compares it to the checksum bit stored in the ROM.

Each time a user turns the terminal on, the power-on self-test executes. If the test detects an error, an error message appears in the lower right-hand corner of the display. Table 3-1 defines these error messages. If any of these messages do appear, replace the microprocessor board.

Table 3-1 Error Message Definitions

Error Message	IC Location	Definition
0	1E	RAM failure in the first 2K block
1	1D	RAM failure in the second 2K block
P	1J	Control PROM error
R	3F or 1C	Display row buffer error
9	6J (TTL PCB) 5J (Gate Array PCB)	EAROM checksum error
X	NA	MODEM port error
Y	NA	AUX port error
Z	3K	CPU failure


DIAGNOSTIC SELF-TEST

The you can start the terminal diagnostic self-test routine in setup. This test routine includes the power-on self-test and the telecommunications circuitry tests. Two special jumpers allow the communications test to function (see Figure 3-1 for jumper definitions). After you start it, the diagnostic test continues to run until you stop it. If the test detects an error, an error message appears in the lower right-hand corner of the CRT (see Table 3-1 for error message definitions).

Follow these steps to start the diagnostic self-test:

1. Plug in the terminal.
2. Install a test jumper on both the AUX and MODEM ports.
3. Turn the power switch ON.
4. Hold down SHIFT, then press SETUP.
5. Press ESC. This returns the terminal to default parameters.
6. Press ▼ key until the TEST parameter appears on the bottom row of the screen.
7. Press ► key until the cursor highlights the TEST parameter field.
8. Press the spacebar. This toggles the TEST parameter field to ON.
9. Start the self-test by holding SHIFT, while you press the SETUP and y keys. The test runs until you stop it.
10. To stop the self-test, hold down SHIFT, then press SETUP again, then remove the jumpers.

Figure 3-1 Test Jumper




TROUBLESHOOTING


This section contains the troubleshooting flowchart, a power supply quick-reference procedure, a procedure to check the horizontal-synchronization signal, and a vertical-hold procedure for revision A monitor/power supply PCBs.



Troubleshooting Flowchart


The troubleshooting flowchart can help you locate faulty modules. Start at the beginning, and follow the questions in the decision boxes. If any step requires a special procedure, you can find a reference number next to the block. We have keyed the reference numbers that appear in the flowchart to the legend at the bottom of the page. If the flowchart doesn't cover the symptoms the terminal shows, look at "Theory of Operations," Chapter 6 and Appendix C, "Schematics."

Figure 3-2 Troubleshooting Flowchart










Power Supply Check from the Microprocessor PCB

You can quickly isolate problems if you check voltages on the microprocessor board. If all voltages at connector J4 are within tolerance, the microprocessor board is at fault (Figure 3-3). If they aren't within tolerance, go to "Adjustments and Alignments," Chapter 4, and adjust the power supply. If you can't adjust the power supply to meet the tolerances, you may need to replace it.

For quick reference, you can check four of the five power supply voltages on the microprocessor board without opening the cover on the monitor (the fifth, +24.5V, never reaches the microprocessor PCB).

Figure 3-3 Power Connector at the Microprocessor PCB



Tools required:

Voltmeter, Phillips screwdriver

1. Turn the monitor OFF.
2. Remove two No. 1 Phillips screws holding the rear panel in place. Pull the microprocessor PCB two inches out of the unit.
3. Find connector J4 on the microprocessor board.
4. Attach one lead from the DVM to J4-10, ground.

Troubleshooting 3-8

5. Turn the monitor on.
6. Check the +5V power supply on J4-12. Look for +5V, ± 2 percent. See the troubleshooting flowchart if the signal isn't within tolerance.
7. Check the +12V power supply on J4-6. Look for +12V, ± 5 percent. See the troubleshooting flowchart if the signal isn't within tolerance.
8. Check the -12V power supply on J4-7. Look for -12V, ± 5 percent. See the troubleshooting flowchart if the signal isn't within tolerance.
9. Check the -23V power supply on J4-11. Look for -23V, ± 5 percent. See the troubleshooting flowchart if the signal isn't within tolerance.

Checking Horizontal Synchronization

Checking the horizontal synchronization helps determine which PCB to replace: either the microprocessor PCB or the monitor/power supply PCB.

Tools Required:

Oscilloscope

1. Find connector J4 on the microprocessor PCB (see Figure 3-3).
2. Touch J4-4 with the oscilloscope probe. Look for a 44 μ s, ± 10 percent, pulse, 4.8 to 5Vp-p. If the horizontal synchronization signal is within tolerance, replace the monitor/power supply PCB. If it isn't within tolerance, replace the microprocessor PCB. See the troubleshooting flowchart.

Adjusting Vertical Hold

On a few early terminals, the monitor/power supply PCB has an extra potentiometer to adjust vertical hold. You can find it next to HGT, VR302, directly below the anode cap. If you need to adjust it, this is the procedure:

1. Display a full screen of E's (see "Adjustments and Alignments," Chapter 4).
2. Turn the vertical hold potentiometer until the display rolls in one direction.
3. Turn the vertical hold potentiometer until the display rolls in the other direction.

4. Center the potentiometer; the display should be steady.
If it isn't steady, see the troubleshooting flowchart.

APPENDIX D SERVICING THE WY-50+

INTRODUCTION TO WY-50+ MAINTENANCE

Servicing the WY-50+ is nearly the same as servicing the WY-50. Major feature differences include the amber screen, additional compatible modes, a bi-directional AUX port, Wyseword standard, and multiple pages of memory (two standard, four optional). New servicing features include an expanded set of field diagnostics, a keyboard function test, a test to check all character sets, and two new built-in test patterns for display alignment.

TROUBLESHOOTING

Added troubleshooting features include an improved self-test, a new diagnostic self-test, a communication port test, a keyboard function test, an attribute/character font test, and a new display to check all attributes.

Note--Running the diagnostic tests described here (other than the power-on self-test) defaults all setup parameters and function keys.

Power-On Self-Test

When a user turns the terminal on, it performs a self-test of the logic PCB. If the self-test discovers a failure, an alphanumeric error code indicating failure type will appear in the lower-right corner of the display. An error code usually indicates logic PCB replacement. Table D-1 lists and explains the error codes.

Table D-1 Power-On Self-Test Error Codes

Error Message	Error Type
0	RAM bank 0
1	RAM bank 1
K	Reinitialize EARAM (Press the SETUP key to continue or turn off the terminal, then on again. Replace logic PCB only if error appears repeatedly.)
P	Code ROM checksum
Z	Processor RAM

The self-test checks RAM, EAROM, and the CPU. The RAM test is a read/write test that checks all 8K of RAM, or all 16K if additional memory is installed on the logic PCB. The CPU test checks 128 bytes of RAM in the CPU, the data lines, and the address lines. The EAROM test calculates the EAROM's checksum, and compares it to the checksum bit stored in the ROM.

FIELD DIAGNOSTICS

The WY-50+ contains four new field diagnostics:

- o The System Diagnostic Test, an expanded version of the diagnostic self-test on page 3-2 of the WY-50 Maintenance Manual.
- o A Transmit/Receive Test for the communications ports.
- o A Keyboard Function Test.
- o An Attribute/Character Font Test

The following sections describe the diagnostic procedures, the new error codes, and the new test connectors and cables.

System Diagnostic Test

This test is an expanded version of the power-on self-test. It checks memory, buffers, the CPU, and communications.

Follow these steps to perform the system diagnostic test:

1. Turn off the terminal.
2. Install the system diagnostic test connectors on the AUX and MODEM ports (see page D-4 for connector definitions).
3. Turn on the terminal.
4. Hold down the SHIFT key, then press the SETUP key.
5. Press the cursor DOWN key until the TEST parameter appears on the bottom line of the screen.
6. Press the cursor LEFT key once. The cursor highlights the TEST field.
7. Press the spacebar. This toggles the test field on.
8. Leave setup mode by holding down the SHIFT key and pressing the SETUP key again.
9. Save the selection by pressing the Y key. This starts the diagnostic self-test.

If the system diagnostic test doesn't find any errors, a flashing pattern should appear on the screen.

If it does find an error, the screen will blank and an error code will appear in the lower-right corner of the display. Replace the logic PCB.

Table D-2 lists and describes the system diagnostic test error codes.

Table D-2 System Diagnostic Test Error Codes

Error Message	Error Type
0	Buffer RAM, IC 0
1	Buffer RAM, IC 1 (if memory is expanded)
9	EAROM
R	Row Buffer
K	No initialization on power-up
A	Modem, RTS to CTS
C	Modem, DTR to DCD
E	AUX Ready to AUX RTS
P	Control PROM
Z	8031 processor
X	MODEM port loopback
Y	AUX port loopback

Caution--If you save the ON test parameter, turn off the power, and remove the test connectors, an error condition will result the next time someone turns on the terminal. Remember to default the terminal before returning it to the user.

Follow these steps to stop the system diagnostic test:

1. Hold down the space bar until the flashing pattern stops.
2. Turn the terminal off.
3. Remove the test connectors. Default the terminal.

System Diagnostic Test Connector Definitions--The diagnostic self-test connectors for both the MODEM and the AUX ports are made from 25-pin, male, D-type connectors. (You can find information to order ready-made connector sets under Parts List on page D-10.)

Connect these pins:

MODEM Port

Pin 2 to Pin 3 (TxD to RxD)
Pin 4 to Pin 5 (RTS to CTS)
Pin 8 to Pin 20 (DCD to DTR)

AUX Port

Pin 2 to Pin 3 (TxD to RxD)
Pin 6 to Pin 20 (DSR to DTR)

Transmit/Receive Communication Port Test

This test transmits data between the MODEM and AUX ports. If either port doesn't receive or recognize the data from the other port, an error code will appear on the screen.

Follow these steps to perform the test:

1. Turn off the terminal.
2. Install the communication port test cable on the AUX and MODEM ports (see page D-5 for a cable definition).
3. Turn on the terminal.
4. Hold down the SHIFT key, then press the SETUP key.
5. Press the cursor DOWN key until the TEST parameter appears on the bottom line of the screen.
6. Press the cursor LEFT key once. The cursor highlights the TEST field.
7. Press the spacebar. This toggles the test field on.
8. Leave setup by holding down the SHIFT key and pressing the SETUP key again.
9. Save the selection by pressing the Y key. This starts the communications port test.

If the communication port test doesn't find any errors, a flashing test pattern should appear on the screen.

If the communication port test does find an error, the screen will blank and an error code will appear in the lower-right corner of the display. Replace the logic PCB. Table D-3 lists and describes the error codes.

Table D-3 Transmit/Receive Communication Port Test Error Codes

Error Message	Error Type
W	Xmit/Rcv error, MODEM to AUX
Z	Xmit/Rcv error, AUX to MODEM

Note--Error messages listed on other tables may appear when this test runs, but most errors will be those listed above.

Caution--If you save the ON test parameter, turn off the power, and remove the test connectors, an error condition will result the next time someone turns on the terminal. Remember to default the terminal before returning it to the user.

Follow these steps to stop the test:

1. Hold down the SETUP key until the flashing pattern stops.
2. Turn the terminal off.
3. Remove the test cable. Default the terminal.

Transmit/Receive Communication Port Test Cable Definitions--The transmit/receive communication port test cable requires two 25-pin, male, D-type connectors, and wire to connect pins on each connector and to connect the two connectors together. (You can find information to order ready-made cables under Parts List on page D-10.)

Connect these pins:

MODEM Port (DTE)		AUX Port (DCE)
Pin 2 (TxD)	to	Pin 2 (RxD)
Pin 3 (RxD)	to	Pin 3 (TxD)
Pins 4 to 5		Pins 6 to 20
Pins 8 to 20		

Keyboard Function Test

The keyboard function test checks the keyboard.

Note--The keyboard function test does not test the following keys: SHIFT, FUNCT, CAPS LOCK, SETUP, BREAK, or CTRL. If you press ENTER, the terminal will return to the system diagnostic test. Pressing function keys F1 through F16 will change attributes on portions of the test screen. .

Follow these instructions to perform the keyboard test:

1. Start the system diagnostic test described on page D-2.
2. Hold down the space bar until the test pattern stops flashing.
3. Hold down the CTRL key, then press the A key until you see the screen in Figure D-1.
4. Find the bottom line of "m"s. Press the letter keys that you are testing, and watch the letters change in the middle of the bottom line.


If the letter keys in question don't work, replace the keyboard PCB.

If the letters do change during the test, but fail to respond during normal operation, check the logic PCB or the computer.

Follow these steps to stop the test:

1. Press the SETUP key until the flashing pattern stops.
2. Turn the terminal off.
3. Remove the test connectors. Default the terminal.

Figure D-1 Keyboard Function Test Pattern



Attribute/Character Font Test

This test allows you to check all the attributes and the character font.

Follow these steps to perform the test:


1. Start the system diagnostic test described on page D-2.
2. Hold the SETUP key down until the test pattern stops flashing.
3. Hold the CTRL key down, then press the A key until you see the screen in Figure D-2.
4. Look for the following features:

Attributes: Normal, Blank, Blink, Underline, Dim, and Reverse

A full character set

If one or more of the features doesn't appear, replace the logic PCB.

Figure D-2 Attribute/Character Font Test Pattern



Follow these steps to stop the test:

1. Press the SETUP key until the flashing pattern stops.
2. Turn the terminal off.
3. Remove the test connectors. Default the terminal.


ALIGNMENT AND ADJUSTMENT

This terminal has two new test patterns, which you can call to align the display more accurately and quickly: Pattern M and Pattern O.

Pattern M

Pattern M helps you detect and correct linearity, brightness, and focus (see Figure D-3). This pattern is an 80-column display of characters. Two blocks in the center of the pattern indicate brightness: dim and normal.

Figure D-3 Pattern M



Pattern 0

Pattern 0 helps you detect and correct pincushion, tilt, centering, and size problems (see Figure D-4). This pattern is a full-reverse, normal brightness display in 80-column format. Two pairs of parallel lines cross in the center, making four quadrants. Two additional vertical lines, one on either side of the pattern, indicate brightness intensity levels.

Note--You can verify the display tolerances using a display reticle, available from WYSE, Part No. 09-001-03. Instructions to use the reticle are included with it.

Figure D-4 Pattern 0




Table D-4 lists adjustments, display problems, and the pattern that is best suited to make the adjustment.

Table D-4 Test Pattern Problems and Adjustments

Test Pattern	Display Problems	Adjustments
M	Letters at the top of the display aren't the same height as those at the bottom of the display	Linearity
M	Fuzzy letters	Focus
M	Too bright; too dim; raster scan lines show	Brightness
O	Too short or too tall	Height
O	Too wide or too narrow	Width
O	Not centered	Centering
O	Not level	Yoke Lock
O	Pincushioning, barreling, crooked edges, corners sag or move out of tolerance	Display magnets

PARTS LIST

The WY-50+ contains three new assemblies that differ from the standard WY-50 terminal: the Logic PCB, the Monitor/Power Supply PCB, and the Amber CRT. The terminal also comes with test connectors and cables. You can order all other replaceable units with the spare part numbers assigned to the WY-50.

Part Number	Description
840293-01	WY-50+ Logic PCB
99-019-02	WY-50+ Monitor/Power PCB
780026-01	WY-50+ Amber CRT
94-0233-01	WY-50+ System Diagnostic Test Connector Set
94-0238-01	WY-50+ Transmit/Receive Comm Port Test Cable
09-001-03	WY-50+ Display Reticle

SCHEMATICS


See Appendix C, "Schematics," to find schematic diagrams of the WY-50+ Logic PCB and Monitor/Power Supply PCB.

NOTES:
 1. ALL RESISTORS ARE 1/4 W, 5% UNLESS OTHERWISE SPECIFIED.
 2. ALL CAPACITORS ARE IN UF UNLESS OTHERWISE SPECIFIED.

FUSE: 2A, FOR 115 VAC
 2A, FOR 230 VAC

ADJ. VR101: +23.5V
 VR102: +5.00V
 VR201: FOCUS
 VR202: SUB-BART
 VR302: V-MGT
 VR303: V-LIN


REV	NO	DATE	DESCRIPTION	BY	APP
1	1		SEE E10 (P)		
2	1				
3	1				
4	1				
5	1				
6	1				
7	1				
8	1				
9	1				
10	1				
11	1				
12	1				
13	1				
14	1				
15	1				
16	1				



VIDEO (1) - WHITE
 GND (2) - BLACK
 DIM (3) - ORANGE
 H-SYNC (4) - YELLOW
 V-SYNC (5) - GREEN
 +12V (6) - BLUE
 -12V (7) - GRAY
 +5V (8) - RED
 GND (9) - BLACK
 GND (10) - BLACK
 +23V (11) - PURPLE
 +5V (12) - RED

MPS LOGIC HARNESS
 94-034-01

99-019-01 WY-50		PARTS LIST	
APPLICATION		THIRD ANGLE PROJECTION	
WY-50 MONITOR POWER SUPPLY		WY-50 MONITOR POWER SUPPLY	
SCALE		SHEET	




PARTS LIST		PARTS LIST	
QTY	DESCRIPTION	QTY	DESCRIPTION
1	MC14694	1	2611-B
1	LS157	1	LS154
1	LS153	1	LS152
1	LS151	1	LS150
1	LS149	1	LS148
1	LS147	1	LS146
1	LS145	1	LS144
1	LS143	1	LS142
1	LS141	1	LS140
1	LS139	1	LS138
1	LS137	1	LS136
1	LS135	1	LS134
1	LS133	1	LS132
1	LS131	1	LS130
1	LS129	1	LS128
1	LS127	1	LS126
1	LS125	1	LS124
1	LS123	1	LS122
1	LS121	1	LS120
1	LS119	1	LS118
1	LS117	1	LS116
1	LS115	1	LS114
1	LS113	1	LS112
1	LS111	1	LS110
1	LS109	1	LS108
1	LS107	1	LS106
1	LS105	1	LS104
1	LS103	1	LS102
1	LS101	1	LS100
1	LS99	1	LS98
1	LS97	1	LS96
1	LS95	1	LS94
1	LS93	1	LS92
1	LS91	1	LS90
1	LS89	1	LS88
1	LS87	1	LS86
1	LS85	1	LS84
1	LS83	1	LS82
1	LS81	1	LS80
1	LS79	1	LS78
1	LS77	1	LS76
1	LS75	1	LS74
1	LS73	1	LS72
1	LS71	1	LS70
1	LS69	1	LS68
1	LS67	1	LS66
1	LS65	1	LS64
1	LS63	1	LS62
1	LS61	1	LS60
1	LS59	1	LS58
1	LS57	1	LS56
1	LS55	1	LS54
1	LS53	1	LS52
1	LS51	1	LS50
1	LS49	1	LS48
1	LS47	1	LS46
1	LS45	1	LS44
1	LS43	1	LS42
1	LS41	1	LS40
1	LS39	1	LS38
1	LS37	1	LS36
1	LS35	1	LS34
1	LS33	1	LS32
1	LS31	1	LS30
1	LS29	1	LS28
1	LS27	1	LS26
1	LS25	1	LS24
1	LS23	1	LS22
1	LS21	1	LS20
1	LS19	1	LS18
1	LS17	1	LS16
1	LS15	1	LS14
1	LS13	1	LS12
1	LS11	1	LS10
1	LS9	1	LS8
1	LS7	1	LS6
1	LS5	1	LS4
1	LS3	1	LS2
1	LS1	1	LS0

WYSE TECHNOLOGY INCORPORATED
LOGIC BOARD WY-50+

SIZE: 11.5" x 11.5" (280mm x 280mm)
Dwg No: 96-058-05
REV: 1
DATE: 11/1/84
BY: [Signature]
CHECKED: [Signature]
APPROVED: [Signature]

THIS DRAWING CONTAINS INFORMATION PROPRIETARY TO WYSE TECHNOLOGY, INC. ANY REPRODUCTION, DISSEMINATION, OR COPIING OF THIS DOCUMENT WITHOUT THE WRITTEN PERMISSION OF WYSE TECHNOLOGY, INC. IS PROHIBITED.

REV. NO.		96-019-02	REV.	DATE	
			1	APR	
REVISIONS					
REV.	REF.	DESCRIPTION		DATE	APPROVED
# 916	A	RTG		11-11-88	
# 1070	A(1)	REDRAW FOR CLARITY, NO CHANGES		12-11-95	





- 1 VIDEO WHITE
- 2 GND BLACK
- 3 DIM ORANGE
- 4 H-SYNC YELLOW
- 5 V-SYNC GREEN
- 6 +12V BLUE
- 7 -12V GREY
- 8 +5V RED
- 9 GND BLACK
- 10 GND BLACK
- 11 -23V PURPLE
- 12 +5V RED

LOGIC HARNESS
94-034-01


YOKE HARNESS
94014-01

WY-50+		WYSE TECHNOLOGY, INC.	
APPLICATION		DATE	
THIRD ANGLE PROJECTION		SCALE	
DO NOT SCALE DRAWING		SHEET 1 OF 1	






REV		DESCRIPTION	DATE	BY
1	1	Change R2, R3, R4 from 22K to 10K	11-2-83	11-2-83
2	2	Change R5, R6, R7 from 22K to 10K	11-2-83	11-2-83
3	3	Change R8, R9, R10 from 22K to 10K	11-2-83	11-2-83
4	4	Change R11, R12, R13 from 22K to 10K	11-2-83	11-2-83
5	5	Change R14, R15, R16 from 22K to 10K	11-2-83	11-2-83
6	6	Change R17, R18, R19 from 22K to 10K	11-2-83	11-2-83
7	7	Change R20, R21, R22 from 22K to 10K	11-2-83	11-2-83
8	8	Change R23, R24, R25 from 22K to 10K	11-2-83	11-2-83
9	9	Change R26, R27, R28 from 22K to 10K	11-2-83	11-2-83
10	10	Change R29, R30, R31 from 22K to 10K	11-2-83	11-2-83
11	11	Change R32, R33, R34 from 22K to 10K	11-2-83	11-2-83
12	12	Change R35, R36, R37 from 22K to 10K	11-2-83	11-2-83
13	13	Change R38, R39, R40 from 22K to 10K	11-2-83	11-2-83
14	14	Change R41, R42, R43 from 22K to 10K	11-2-83	11-2-83
15	15	Change R44, R45, R46 from 22K to 10K	11-2-83	11-2-83
16	16	Change R47, R48, R49 from 22K to 10K	11-2-83	11-2-83
17	17	Change R50, R51, R52 from 22K to 10K	11-2-83	11-2-83
18	18	Change R53, R54, R55 from 22K to 10K	11-2-83	11-2-83
19	19	Change R56, R57, R58 from 22K to 10K	11-2-83	11-2-83
20	20	Change R59, R60, R61 from 22K to 10K	11-2-83	11-2-83
21	21	Change R62, R63, R64 from 22K to 10K	11-2-83	11-2-83
22	22	Change R65, R66, R67 from 22K to 10K	11-2-83	11-2-83
23	23	Change R68, R69, R70 from 22K to 10K	11-2-83	11-2-83
24	24	Change R71, R72, R73 from 22K to 10K	11-2-83	11-2-83
25	25	Change R74, R75, R76 from 22K to 10K	11-2-83	11-2-83
26	26	Change R77, R78, R79 from 22K to 10K	11-2-83	11-2-83
27	27	Change R80, R81, R82 from 22K to 10K	11-2-83	11-2-83
28	28	Change R83, R84, R85 from 22K to 10K	11-2-83	11-2-83
29	29	Change R86, R87, R88 from 22K to 10K	11-2-83	11-2-83
30	30	Change R89, R90, R91 from 22K to 10K	11-2-83	11-2-83
31	31	Change R92, R93, R94 from 22K to 10K	11-2-83	11-2-83
32	32	Change R95, R96, R97 from 22K to 10K	11-2-83	11-2-83
33	33	Change R98, R99, R100 from 22K to 10K	11-2-83	11-2-83
34	34	Change R101, R102, R103 from 22K to 10K	11-2-83	11-2-83
35	35	Change R104, R105, R106 from 22K to 10K	11-2-83	11-2-83
36	36	Change R107, R108, R109 from 22K to 10K	11-2-83	11-2-83
37	37	Change R110, R111, R112 from 22K to 10K	11-2-83	11-2-83
38	38	Change R113, R114, R115 from 22K to 10K	11-2-83	11-2-83
39	39	Change R116, R117, R118 from 22K to 10K	11-2-83	11-2-83
40	40	Change R119, R120, R121 from 22K to 10K	11-2-83	11-2-83
41	41	Change R122, R123, R124 from 22K to 10K	11-2-83	11-2-83
42	42	Change R125, R126, R127 from 22K to 10K	11-2-83	11-2-83
43	43	Change R128, R129, R130 from 22K to 10K	11-2-83	11-2-83
44	44	Change R131, R132, R133 from 22K to 10K	11-2-83	11-2-83
45	45	Change R134, R135, R136 from 22K to 10K	11-2-83	11-2-83
46	46	Change R137, R138, R139 from 22K to 10K	11-2-83	11-2-83
47	47	Change R140, R141, R142 from 22K to 10K	11-2-83	11-2-83
48	48	Change R143, R144, R145 from 22K to 10K	11-2-83	11-2-83
49	49	Change R146, R147, R148 from 22K to 10K	11-2-83	11-2-83
50	50	Change R149, R150, R151 from 22K to 10K	11-2-83	11-2-83
51	51	Change R152, R153, R154 from 22K to 10K	11-2-83	11-2-83
52	52	Change R155, R156, R157 from 22K to 10K	11-2-83	11-2-83
53	53	Change R158, R159, R160 from 22K to 10K	11-2-83	11-2-83
54	54	Change R161, R162, R163 from 22K to 10K	11-2-83	11-2-83
55	55	Change R164, R165, R166 from 22K to 10K	11-2-83	11-2-83
56	56	Change R167, R168, R169 from 22K to 10K	11-2-83	11-2-83
57	57	Change R170, R171, R172 from 22K to 10K	11-2-83	11-2-83
58	58	Change R173, R174, R175 from 22K to 10K	11-2-83	11-2-83
59	59	Change R176, R177, R178 from 22K to 10K	11-2-83	11-2-83
60	60	Change R179, R180, R181 from 22K to 10K	11-2-83	11-2-83
61	61	Change R182, R183, R184 from 22K to 10K	11-2-83	11-2-83
62	62	Change R185, R186, R187 from 22K to 10K	11-2-83	11-2-83
63	63	Change R188, R189, R190 from 22K to 10K	11-2-83	11-2-83
64	64	Change R191, R192, R193 from 22K to 10K	11-2-83	11-2-83
65	65	Change R194, R195, R196 from 22K to 10K	11-2-83	11-2-83
66	66	Change R197, R198, R199 from 22K to 10K	11-2-83	11-2-83
67	67	Change R200, R201, R202 from 22K to 10K	11-2-83	11-2-83
68	68	Change R203, R204, R205 from 22K to 10K	11-2-83	11-2-83
69	69	Change R206, R207, R208 from 22K to 10K	11-2-83	11-2-83
70	70	Change R209, R210, R211 from 22K to 10K	11-2-83	11-2-83
71	71	Change R212, R213, R214 from 22K to 10K	11-2-83	11-2-83
72	72	Change R215, R216, R217 from 22K to 10K	11-2-83	11-2-83
73	73	Change R218, R219, R220 from 22K to 10K	11-2-83	11-2-83
74	74	Change R221, R222, R223 from 22K to 10K	11-2-83	11-2-83
75	75	Change R224, R225, R226 from 22K to 10K	11-2-83	11-2-83
76	76	Change R227, R228, R229 from 22K to 10K	11-2-83	11-2-83
77	77	Change R230, R231, R232 from 22K to 10K	11-2-83	11-2-83
78	78	Change R233, R234, R235 from 22K to 10K	11-2-83	11-2-83
79	79	Change R236, R237, R238 from 22K to 10K	11-2-83	11-2-83
80	80	Change R239, R240, R241 from 22K to 10K	11-2-83	11-2-83
81	81	Change R242, R243, R244 from 22K to 10K	11-2-83	11-2-83
82	82	Change R245, R246, R247 from 22K to 10K	11-2-83	11-2-83
83	83	Change R248, R249, R250 from 22K to 10K	11-2-83	11-2-83
84	84	Change R251, R252, R253 from 22K to 10K	11-2-83	11-2-83
85	85	Change R254, R255, R256 from 22K to 10K	11-2-83	11-2-83
86	86	Change R257, R258, R259 from 22K to 10K	11-2-83	11-2-83
87	87	Change R260, R261, R262 from 22K to 10K	11-2-83	11-2-83
88	88	Change R263, R264, R265 from 22K to 10K	11-2-83	11-2-83
89	89	Change R266, R267, R268 from 22K to 10K	11-2-83	11-2-83
90	90	Change R269, R270, R271 from 22K to 10K	11-2-83	11-2-83
91	91	Change R272, R273, R274 from 22K to 10K	11-2-83	11-2-83
92	92	Change R275, R276, R277 from 22K to 10K	11-2-83	11-2-83
93	93	Change R278, R279, R280 from 22K to 10K	11-2-83	11-2-83
94	94	Change R281, R282, R283 from 22K to 10K	11-2-83	11-2-83
95	95	Change R284, R285, R286 from 22K to 10K	11-2-83	11-2-83
96	96	Change R287, R288, R289 from 22K to 10K	11-2-83	11-2-83
97	97	Change R290, R291, R292 from 22K to 10K	11-2-83	11-2-83
98	98	Change R293, R294, R295 from 22K to 10K	11-2-83	11-2-83
99	99	Change R296, R297, R298 from 22K to 10K	11-2-83	11-2-83
100	100	Change R299, R300, R301 from 22K to 10K	11-2-83	11-2-83
101	101	Change R302, R303, R304 from 22K to 10K	11-2-83	11-2-83
102	102	Change R305, R306, R307 from 22K to 10K	11-2-83	11-2-83
103	103	Change R308, R309, R310 from 22K to 10K	11-2-83	11-2-83
104	104	Change R311, R312, R313 from 22K to 10K	11-2-83	11-2-83
105	105	Change R314, R315, R316 from 22K to 10K	11-2-83	11-2-83
106	106	Change R317, R318, R319 from 22K to 10K	11-2-83	11-2-83
107	107	Change R320, R321, R322 from 22K to 10K	11-2-83	11-2-83
108	108	Change R323, R324, R325 from 22K to 10K	11-2-83	11-2-83
109	109	Change R326, R327, R328 from 22K to 10K	11-2-83	11-2-83
110	110	Change R329, R330, R331 from 22K to 10K	11-2-83	11-2-83
111	111	Change R332, R333, R334 from 22K to 10K	11-2-83	11-2-83
112	112	Change R335, R336, R337 from 22K to 10K	11-2-83	11-2-83
113	113	Change R338, R339, R340 from 22K to 10K	11-2-83	11-2-83
114	114	Change R341, R342, R343 from 22K to 10K	11-2-83	11-2-83
115	115	Change R344, R345, R346 from 22K to 10K	11-2-83	11-2-83
116	116	Change R347, R348, R349 from 22K to 10K	11-2-83	11-2-83
117	117	Change R350, R351, R352 from 22K to 10K	11-2-83	11-2-83
118	118	Change R353, R354, R355 from 22K to 10K	11-2-83	11-2-83
119	119	Change R356, R357, R358 from 22K to 10K	11-2-83	11-2-83
120	120	Change R359, R360, R361 from 22K to 10K	11-2-83	11-2-83
121	121	Change R362, R363, R364 from 22K to 10K	11-2-83	11-2-83
122	122	Change R365, R366, R367 from 22K to 10K	11-2-83	11-2-83
123	123	Change R368, R369, R370 from 22K to 10K	11-2-83	11-2-83
124	124	Change R371, R372, R373 from 22K to 10K	11-2-83	11-2-83
125	125	Change R374, R375, R376 from 22K to 10K	11-2-83	11-2-83
126	126	Change R377, R378, R379 from 22K to 10K	11-2-83	11-2-83
127	127	Change R380, R381, R382 from 22K to 10K	11-2-83	11-2-83
128	128	Change R383, R384, R385 from 22K to 10K	11-2-83	11-2-83
129	129	Change R386, R387, R388 from 22K to 10K	11-2-83	11-2-83
130	130	Change R389, R390, R391 from 22K to 10K	11-2-83	11-2-83
131	131	Change R392, R393, R394 from 22K to 10K	11-2-83	11-2-83
132	132	Change R395, R396, R397 from 22K to 10K	11-2-83	11-2-83
133	133	Change R398, R399, R400 from 22K to 10K	11-2-83	11-2-83
134	134	Change R401, R402, R403 from 22K to 10K	11-2-83	11-2-83
135	135	Change R404, R405, R406 from 22K to 10K	11-2-83	11-2-83
136	136	Change R407, R408, R409 from 22K to 10K	11-2-83	11-2-83
137	137	Change R410, R411, R412 from 22K to 10K	11-2-83	11-2-83
138	138	Change R413, R414, R415 from 22K to 10K	11-2-83	11-2-83
139	139	Change R416, R417, R418 from 22K to 10K	11-2-83	11-2-83
140	140	Change R419, R420, R421 from 22K to 10K	11-2-83	11-2-83
141	141	Change R422, R423, R424 from 22K to 10K	11-2-83	11-2-83
142	142	Change R425, R426, R427 from 22K to 10K	11-2-83	11-2-83
143	143	Change R428, R429, R430 from 22K to 10K	11-2-83	11-2-83
144	144	Change R431, R432, R433 from 22K to 10K	11-2-83	11-2-83
145	145	Change R434, R435, R436 from 22K to 10K	11-2-83	11-2-83
146	146	Change R437, R438, R439 from 22K to 10K	11-2-83	11-2-83
147	147	Change R440, R441, R442 from 22K to 10K	11-2-83	11-2-83
148	148	Change R443, R444, R445 from 22K to 10K	11-2-83	11-2-83
149	149	Change R446, R447, R448 from 22K to 10K	11-2-83	11-2-83
150	150	Change R449, R450, R451 from 22K to 10K	11-2-83	11-2-83
151	151	Change R452, R453, R454 from 22K to 10K	11-2-83	11-2-83
152	152	Change R455, R456, R457 from 22K to 10K	11-2-83	11-2-83
153	153	Change R458, R459, R460 from 22K to 10K	11-2-83	11-2-83
154	154	Change R461, R462, R463 from 22K to 10K	11-2-83	11-2-83
155	155	Change R464, R465, R466 from 22K to 10K	11-2-83	11-2-83
156	156	Change R467, R468, R469 from 22K to 10K	11-2-83	11-2-83
157	157	Change R470, R471, R472 from 22K to 10K	11-2-83	11-2-83
158	158	Change R473, R474, R475 from 22K to 10K	11-2-83	11-2-83
159	159	Change R476, R477, R478 from 22K to 10K	11-2-83	11-2-83
160	160	Change R479, R480, R481 from 22K to 10K	11-2-83	11-2-83
161	161	Change R482, R483, R484 from 22K to 10K	11-2-83	11-2-83
162	162	Change R485, R486, R487 from 22K to 10K	11-2-83	11-2-83
163	163	Change R488, R489, R490 from 22K to 10K	11-2-83	11-2-83
164	164	Change R491, R492, R493 from 22K to 10K	11-2-83	11-2-83
165	165	Change R494, R495, R496 from 22K to 10K	11-2-83	11-2-83
166	166	Change R497, R498, R499 from 22K to 10K	11-2-83	11-2-83
167	167	Change R500, R501, R502 from 22K to 10K	11-2-83	11-2-83
168	168	Change R503, R504, R505 from 22K to 10K	11-2-83	11-2-83
169	169	Change R506, R507, R508 from 22K to 10K	11-2-83	11-2-83
17				



REVISIONS			
REV	DESCRIPTION	DATE	APPROVED




ROW BUFFER DIAGNOSTIC REGISTER.

QTY REQD	FSCM NO	PART OR IDENTIFYING NO	NOMENCLATURE OR DESCRIPTION	MATERIAL SPECIFICATION
PARTS LIST				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .005 ± .005		CONTRACT NO.		WYSE TECHNOLOGY LOGIC BOARD, WY50
MATERIAL		APPROVALS	DATE	
FINISH		DRAWN	CHECKED	
NEXT ASSY USED ON		ISSUED		
APPLICATION		DO NOT SCALE DRAWING		SIZE B FSCM NO. DWG. NO. 96-012-01 REV. D3 SCALE SHEET 7 of 7

DWG. NO. SH REV.

REVISIONS

REV	DESCRIPTION	DATE	APPROVED





HSYNC STRETCHER

QTY REQD	FSCM NO	PART OR IDENTIFYING NO	NOMENCLATURE OR DESCRIPTION	MATERIAL SPECIFICATION
PARTS LIST				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE FRACTIONS DECIMALS ANGLES ± .XX ± .XXX ±			CONTRACT NO	
MATERIAL			APPROVALS	DATE
FINISH			CHECKED	
NEXT ASSY			ISSUED	
USED ON			SIZE B	FSCM NO.
APPLICATION			DWG NO. 96-012-01	REV. D3
DO NOT SCALE DRAWING			SCALE	SHEET 6 of 7

NOTES:

1. HSYNC-, VSYNC-, Require RS232C Receivers.
2. DIM-& VIDEO- Require S37 Drivers.
3. VIDEO- (J1-18) corresponds to Green-output on RGB Graphics Controller. Red- (J1-11) & Blue- (J1-19) are not used on wy-50.
4. Red-, Green-, Blue- require S37 Driver. Both transmit (receive ends of Blue- (J1-19) require diode clamps



GRAPHICS
INTERFACE

QTY REQD	FSCM NO	PART OR IDENTIFYING NO	NOMENCLATURE OR DESCRIPTION	MATERIAL SPECIFICATION
PARTS LIST				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE FRACTIONS DECIMALS ANGLES ± .XX ± .XXX ±			CONTRACT NO	
MATERIAL			APPROVALS	DATE
FINISH			CHECKED	
NEXT ASSY			ISSUED	
USED ON			WYSE TECHNOLOGY	
APPLICATION			LOGIC BOARD, W50	
DO NOT SCALE DRAWING			SIZE B	FSCM NO
			DWG. NO. 96-012-01	REV. D3
			SCALE	SHEET 4 OF 7

NOTES:


1. MOUNT LEL NEAR VLE EDGE.
2. FOR TEST ERROR AT 19200 BAUD.
SUBSTITUTE 2461B & 4.7152 MHZ X-TAL.
MAX Baud RATE WILL BECOME 38400.
3. LS157: COMMON

J1: 25 Pin D MOLEM PORT
J2: 25 Pin D PRINTER PORT

DWG. NO. SH REV.

REVISIONS

REV	DESCRIPTION	DATE	APPROVED
-----	-------------	------	----------




QTY	REQD	FSCM NO	PART OR IDENTIFYING NO	NOMENCLATURE OR DESCRIPTION	MATERIAL SPECIFICATION
PARTS LIST					
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES ± .005 ± .001 ± .001			CONTRACT NO.		
MATERIAL			APPROVALS DATE		
FINISH			DRAWN		
NEXT ASSY			CHECKED		
USED ON			ISSUED		
APPLICATION			DO NOT SCALE DRAWING		
SCALE			SHEET 3 of 7		

WYSE TECHNOLOGY

LOGIC BOARD, WY-50

SIZE B FSCM NO. DWG. NO. 96-012-01 REV. D3






DWG. NO. SH REV.

REVISIONS			
REV.	DESCRIPTION	DATE	APPROVED
B	Rev Dot CLK Oscillator, Inhibit H-Sync on Pwr-Up Replace CLK w/ Dot CLK on graphics Interface		1
C	Add 5.10 Zener & 100Ω Res to EARMCKT.		
D	Add 1 ply to H-Sync, Separate GND for Video to monitor.		
D1	change R5, R29, R25 to 12K ohm, 1/4W 5%		
D2	Remove Sockets, 3L, 3J, 6J		
D3	Location 3F changed to 1K x 8 static Ram Sy 2158A		


QTY REQD	PBCH NO	PART OR IDENTIFYING NO	NUMERICAL OR DESCRIPTION	MATERIAL SPECIFICATION
PARTS LIST				
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE FRACTIONS DECIMALS ANGLES ± .XX ± .XXX ±			CONTRACT NO	
MATERIAL			APPROVALS DATE	
FINISH			DRAWN <i>771.8 Bell</i> 6-8-83	
NEXT ASSY USED ON			CHECKED	
APPLICATION			ISSUED	
DO NOT SCALE DRAWING			SIZE B PBCH NO. DWG. NO. 96-012-01 REV. D3	
			SCALE SHEET 0 of 7	

WYSE TECHNOLOGY

LOGIC BOARD, WY-50




theory of operation 6-4



THIS DRAWING IS THE PROPERTY OF WYSE TECHNOLOGY INC. ANY REPRODUCTION OR TRANSMISSION OF THIS DRAWING WITHOUT THE WRITTEN PERMISSION OF WYSE TECHNOLOGY INC. IS PROHIBITED.

REV	DATE	DESCRIPTION	BY	APPROVED
8916	A	ATC		
91070	1	REORDERED FOR CLARITY, NO CHANGES		




FUSE :
2A FOR 115VAC
1A FOR 230VAC

VR101 : +23.5V
VR102 : +5.00V
VR201 : FOCUS
VR202 : SUB-BAT.
VR302 : V-HGT.
VR303 : V-LIN.


- 1 VIDEO WHITE 7 -12V GREY
2 GND BLACK 8 +5V RED
3 DIM ORANGE 9 GND BLACK
4 H-SYNC YELLOW 10 GND BLACK
5 V-SYNC GREEN 11 -23V PURPLE
6 +12V BLUE 12 +5V RED
- LOGIC HARNESS
94-034-01

YOKE HARNESS
940154-01

WY-50 +		CONTRACT NO.	
THIRD ANGLE PROJECTION		WYSE TECHNOLOGY INCORPORATED	
DO NOT SCALE DRAWING		WY-50 + SCHEMATIC	
DATE		REV	
11-6-85		1	
SIZE 12-10-85		DWG NO 96-019-02	
SCALE		SHEET 1 OF 1	







96-018-01			2	1
REV	DESCRIPTION	DATE	BY	APP
1	CHANGED C21, C27, C29, C64 PER ECN # 447	8/14/87		
2	CONNECTION LEVEL PER ECN # 553			
3	BOM CHANGES PER ECN # 557			
4	BOM CHANGES PER ECN # 557			
5	ADDED MEMORY INSTRUCTION PER ECN # 557			
6	CHANGED C21, C27, C29 PER ECN # 557			
7	CHANGED THE MATERIAL OF D CONN PER ECN # 559			
8	BOM CHANGES PER ECN # 712	5/11/88		
9	SEE ECN # 712	7/14/88		
10	TRANSFER CHANGES (SMT2) FROM M/LR TO W/LR	12/11/88		


1. MOUNT LED NEAR PCB EDGE
2. LS157 - COMMON
3. ALL JUMPERS (J3P) 50" SPACING
4. ALL IC'S EXCEPT U9, U10, U17, U30, U31, U37, U41, U45 AND U48 HAVE INDIVIDUAL 0.1UF BYPASS CAPACITORS

D

C

B

A



NOTE:
 1. 47.4UF @ 25V (+40%) CBLK
 2. C21, C27, C29 0.22uF/50V
 C64 0.01uF/50V

QTY / PACK		PART OF		NOMENCLATURE		INTERNAL	
REQD	NO	IDENT	NO	OR DESCRIPTION		SPECIFICATION	
PARTS LIST							
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES				WYSE TECHNOLOGY			
MATERIAL				LOGIC BOARD, WY50/75			
FINISH				GATE ARRAY VERSION			
TEST PART				REV. 1.0			
USED ON				96-018-01			
APPLICATION				DO NOT SCALE DRAWING			

