CONVERGENCE SCHEMATIC

461 462 463 464 465 466 467 468 469 470 471 472 473 474 475 476 477 478 479 480

A B C D E F G H I J K L

FROM GV_CONV
FROM GH_CONV
FROM AMPMUTE
FROM RV_CONV
FROM RH_CONV
FROM BV_CONV
FROM BH_CONV

HORIZ GREEN
HORIZ RED
HORIZ BLUE
VERT GREEN
VERT RED
VERT BLUE

TO GHR
TO GVR
TO RHR
TO RVR
TO BHR
TO BVR

J19311 J19310 TO CONVERGENCE COILS

ALL INTEGRATED CIRCUITS AND MANY OTHER SEMICONDUCTORS ARE ELECTROSTATICALLY SENSITIVE AND REQUIRE SPECIAL HANDLING TECHNIQUES DESCRIBED UNDER "ELECTROSTATICALLY SENSITIVE (ES) DEVICES" IN THE SAFETY AND SERVICING PRECAUTIONS PUBLICATION.

PRODUCT SAFETY NOTE

COMPONENTS WITH A ⚠ HAVE SPECIAL CHARACTERISTICS IMPORTANT TO SAFETY. BEFORE REPLACING ANY OF THESE COMPONENTS READ CAREFULLY THE PRODUCT SAFETY NOTICE IN THIS SERVICE DATA. DO NOT DEGRADE THE SAFETY OF THE SET THROUGH IMPROPER SERVICING.

SCHEMATIC NOTES

1. RESISTANCE VALUES ARE IN OHMS; K=X1000, Meg=X1,000,000. RESISTORS ARE 1/4W 5%, EXCEPT WHERE INDICATED.
   [ ] INDICATES FLAT MAXI-CHIP COMPONENT, 1/8W EXCEPT WHERE INDICATED.
   / \ INDICATES FLAT MINI-CHIP COMPONENT, 1/16W EXCEPT WHERE INDICATED.
2. CAPACITANCE VALUES 1.0 AND ABOVE ARE IN µF. VALUES BELOW 1.0 ARE IN Pp EXCEPT WHERE INDICATED. VOLTAGE RATING IS 50V EXCEPT WHERE INDICATED.
   [ ] INDICATES FLAT MAXI-CHIP COMPONENT.
   / \ INDICATES FLAT MINI-CHIP COMPONENT.
3. ⏚ DENOTES CHASSIS GROUND. ⊗ INDICATES CONNECTION VIA POINT-TO-POINT WIRE.
   ⌒ —INDICATES JUMPER WIRE.
   ⊶ —INDICATES ZERO OHM CHIP COMPONENT.

PAGE 9–24