

AMPULATOR CALIBRATION PROCEDURE

SETUP:

TUBE MATCHING:	12 o'clock
HUM INJECTION:	minimum
TUBE BIAS:	maximum (class B LED should be lit)
POWER LEVEL:	minimum
All other controls:	don't matter for this procedure

PROCEDURE:

- 1) Turn power switch on with no input or outputs connected. Allow 30 seconds warmup minimum.
- 2) Turn trim pot (the only one in the Ampulator) clockwise until CLEAN (green) LED is lit up.
- 3) Now turn trim pot counter-clockwise and stop just when the CLEAN (green) LED goes off.

