

**Model:** KV-32V68, KV-35V68

**No.** 519

**Subject:** Whistle Sound From Speakers.

**Date:** January 12, 2001

**Symptom:**  
**(1525)**

With TV guide screen ON, when the set is turned OFF there is a strange sound like a whistle sound from the speaker.

**Solution:**

If the customer should complain of the symptom above change the value of C1478, on the "K" Board, as follows.

Ref.	Description Former	Description New	Part Number
C1478	220uf/50v	1000uf/50v	1-126-972-11

