

JVC

SERVICE MANUAL

COLOUR TELEVISION

AV28R25EKS AV28R250EKS

Supplementary

BASIC CHASSIS

JL

We have changed the production country for some parts. As a result, some parts number have been changed. Therefore, this service manual describes only these parts number.
For others, please use the service manual for AV28R25EKS, AV28R250EKS (No.51941, Mar. 2002).

■ DIFFERENCE LIST

● USING PW BOARD (Page 30)

PWB ASS'Y	Model	AV28R25EKS / AV28R250EKS		Remark
		Before	After	
MAIN PWB		SJL-1005A-U2	←	Not change
POWER & DEF PWB		SJL-2003A-U2	SJL-2003A-H3	Interchangeable
CRT SOCKET PWB		SJL-3001A-U2	SJL-3001A-H3	↑
FRONT CONTROL PWB		SJL-8003A-U2	SJL-8003A-H3	↑
SIDE CONTROL PWB		SJL-8101A-U2	SJL-8101A-H3	↑
AV SEL. PWB		SJL0S003A-U2	SJL0S003A-H3	↑
DOLBY PWB		SJL0D001A-U2	←	Not change

Note:

The number of PWB have been changed because the production country of some PWBs has been changed. However, there is no change in component parts.



JVC

VICTOR COMPANY OF JAPAN, LIMITED

HOME AV NETWORK BUSINESS UNIT 12, 3-chome, Moriya-cho, Kanagawa-ku, Yokohama, Kanagawa-prefecture, 221-8528, Japan



Printed in Japan
0208 WPC