

Several versions of the Power/Deflection PCB and the Small Signal PCB were used during production. To ensure proper operation it is critical that components are replaced with the correct value. A bar code label is used to identify which PCB is used. The bar code label is located at 3A (From the back of the unit this will be located towards the front of the instrument) of the Power/Deflection PSB. On the Small Signal PCB this label is located at 4C (Next to the shield around the GenCam IC). The first set of digits on this label will identify which PCB is used (See example in the graphic below). Click the “Notes” button on the Parts List screen. The notes will identify the PCB for that part number.

