

Model: KP-61S65**No.** 364**Subject:** Removal of Protection Sheet**Date:** July 7, 1998**Symptom:****(****)**

The front screen is being damaged when the protective sheet (between the two screens) is being removed improperly. What is the proper method of removing the protection Sheet?

Solution:

Below is the proper method of removing the Protection Sheet. This sheet was installed on serial number range 9000001-9004685 inclusively

To remove this protection sheet

1. Remove the adhesive tape that holds the protection sheet to the top of the Projection TV.
2. Simultaneously grasp both the lower left and right hand corners and **SLOWLY** pull the protection sheet **STRAIGHT DOWN**. If the sheet becomes jammed inside the unit or cut while removing contact your nearest Sony dealer or authorized service center, who will remove the front screen and the protective sheet.

Note: As the surface of the screen scratches easily, do not touch it when removing the protection sheet. **This sheet is only necessary for cross-country transportation of the product. Do not try to replace the protective sheet once it has been removed.**

