



Plasma TV

Chassis : F74A(P_HD)_C45X

Model Code : PL50C450B1XZL

SERVICE Manual

Plasma TV



PL50C450B1

CONTENTS

1. Precaution
2. Product Specification
3. Disassembly & Reassembly
4. Troubleshooting
5. Exploded View & Part List
6. Wiring Diagram

Refer to the service manual in the GSPN (see the rear cover) for the more information.



GSPN (Global Service Partner Network)

Area	Web Site
North America	service.samsungportal.com
Latin America	latin.samsungportal.com
CIS	cis.samsungportal.com
Europe	europe.samsungportal.com
China	china.samsungportal.com
Asia	asia.samsungportal.com
Mideast & Africa	mea.samsungportal.com

This Service Manual is a property of Samsung Electronics Co.,Ltd. Any unauthorized use of Manual can be punished under applicable International and/or domestic law.

© Samsung Electronics Co.,Ltd. **Apr. 2010**
Printed in Korea
AA82-06435A

Table of Contents

1. Precaution

1-1	Safety Precautions	1-1
1-2	Servicing Precautions	1-3
1-3	Static Electricity Precautions.....	1-4
1-4	Installation Precautions.....	1-5

2. Product Specification

2-1	Product Feature	2-1
2-2	Specifications Analysis.....	2-11
2-3	Detail Factory Option	2-13
2-4	Accessories.....	2-15

3. Disassembly & Reassembly

3-1	Overall Disassembly & Reassembly	3-1
-----	--	-----

4. Troubleshooting

4-1	Checkpoints by Error Mode.....	4-1
4-2	Adjustment	4-13
4-3	Upgrade	4-31

5. Exploded View & Part List

5-1	Exploded View	5-1
5-2	Service Item	5-3

6. Wiring Diagram

6-1	Overall Wiring.....	6-1
-----	---------------------	-----