

VR352

VOLTAGE CHARTS

PIF & MPX

MODE PIN No.	TMI						
	STOP	REC	PLAY	REW/ F.FWD	REV/FWD SEARCH	REC PAUSE	PLAY PAUSE
1	0	0	0	0	0	0	0
2	2.4	2.4	2.4	2.4	2.4	2.4	2.4
3	5.1	5.1	5.1	5.1	5.1	5.1	5.1
4	5.1	5.0	5.1	5.1	5.1	5.1	5.1
5	1.3	1.3	1.29	1.34	1.31	1.3	1.30
6	4.0	4.0	4.0	4.0	4.0	3.98	4.0
7	0	0	0	0	0	0	0
8	0	0	0	0	0	0	0
9	4.4	4.7	4.7	4.5	4.7	4.4	4.4
10	4.2	4.6	4.6	4.3	4.6	4.2	4.2

MODE PIN No.	TMI						
	STOP	REC	PLAY	REW/ F.FWD	REV/FWD SEARCH	REC PAUSE	PLAY PAUSE
11	5.1	5.1	5.1	5.1	5.1	5.1	5.1
12	5.1	5.1	5.1	5.1	5.1	5.1	5.1
13	0	0	0	0	0	0	0
14	31.5	31.7	31.6	31.6	31.6	31.5	31.6
15	0	0	0	0	0	0	0
16	0	0	0	0	0	0	0
17	2.28	2.28	2.28	2.28	2.28	2.29	2.28
18	0	0	0	0	0	0	0
19	3.1	3.1	3.1	3.1	3.1	3.1	3.1
20	3.4	3.4	3.4	3.4	3.4	3.4	3.4

MODE PIN No.	IC MPX (IC151)						
	STOP	REC	PLAY	REW/ F.FWD	REV/FWD SEARCH	REC PAUSE	PLAY PAUSE
1	4.0	4.0	4.0	4.0	4.0	4.0	4.0
2	4.0	4.0	4.0	4.0	4.0	4.0	4.0
3	4.2	4.6	4.6	4.2	4.6	4.2	4.2
4	4.4	4.7	4.7	4.4	4.7	4.4	4.4
5	0	0	0	0	0	0	0
6	4	4	4	4	4	4	4
7	3.8	3.8	3.82	3.8	3.82	3.8	3.82
8	4	4	4	4	4	4	4
9	4	4	4	4	4	4	4
10	4.7	4.7	4.7	4.7	4.7	4.7	4.7
11	4	4	4	4	4	4	4
12	1.25	1.25	1.25	1.25	1.25	1.25	1.25
13	1.25	1.25	1.25	1.25	1.25	1.25	1.25
14	0	0	0	0	0	0	0
15	3.1	3.1	3.1	3.1	3.1	3.1	3.1

MODE PIN No.	IC MPX (IC151)						
	STOP	REC	PLAY	REW/ F.FWD	REV/FWD SEARCH	REC PAUSE	PLAY PAUSE
16	9.1	9.1	9.1	9.1	9.1	9.1	9.1
17	4.0	4.0	3.98	3.98	3.98	3.98	3.98
18	4.0	4.0	4.0	4.0	4.0	4.0	4.0
19	3.7	3.7	3.7	3.7	3.7	3.7	3.7
20	3.8	3.8	3.8	3.8	3.8	3.8	3.8
21	4.0	4.0	4.0	4.0	4.0	4.0	4.0
22	3.9	3.94	3.94	3.94	3.94	3.94	3.94
23	4.0	4.0	4.0	4.0	4.0	4.0	4.0
24	1.85	1.85	1.85	1.85	1.85	1.85	1.85
25	4.0	4.0	4.0	4.0	4.0	4.0	4.0
26	4.0	4.0	4.0	4.0	4.0	4.0	4.0
27	2.1	2.1	2.1	2.1	2.1	2.1	2.1
28	3.96	3.96	3.96	3.96	3.96	3.96	3.96
29	0	0	0	0	0	0	0
30	3.98	3.98	3.98	3.98	3.98	3.97	3.98

MODE PIN No.							
	STOP	REC	PLAY	REW/ F.FWD	REV/FWD SEARCH	REC PAUSE	PLAY PAUSE
Q101							
E	2.6	2.6	2.56	2.62	2.56	2.62	2.55
C	0	0	0	0	0	0	0
B	1.9	1.9	1.85	1.91	1.84	1.9	1.83

MODE PIN No.							
	STOP	REC	PLAY	REW/ F.FWD	REV/FWD SEARCH	REC PAUSE	PLAY PAUSE
Q102							
E	0	0	0	0	0	0	0
C	0.17	0.17	0.17	0.17	0	0.17	0
B	0	0	0	0	5.1	0	5.1