

 **THOMSON CONSUMER ELECTRONICS**
Video Cassette Recorder
Basic Service Data

VR352

Addition Models:

VR552/VR554/VR639HF/VR646HF/
VR647HF/VR650HF/VG2051/VG4274



PROSCAN



Technical Publications

P.O. Box 1976 / Indianapolis, Indiana 46206

SERVICE DATA INDEX

	Page Number		Page Number
Block Diagrams		General Information	
Audio	11-4	Abbreviations	1-12
Commercial Advance	11-7	Cleaning & Lubrication	1-4
Hi-Fi Audio	11-5	Safety Precautions	1-2
Interconnect Wiring Diagram	11-1	Specifications	1-3
Power Supply	11-6	Mechanical Adjustments	3-1
Servo & Syscon	11-2	Replacement Parts List	8-1
Video	11-3	Schematic Diagrams	
Circuit Boards		Commercial Advance/CBC	9-9
Main	10-1	Hi-Fi Audio	9-5
Loading Motor	10-2	PIF (2/4 HD)	9-7
A/C Head	10-2	PIF & MPX (Hi-Fi)	9-6
Disassembly	2-1	Power Supply	9-8
Electrical Adjustments	4-1	Servo & Syscon	9-2
Exploded Views		Video & Audio (2/4 HD)	9-4
Instrument	12-1	Video & Audio (Hi-Fi)	9-3
Mechanism	12-2	Troubleshooting Aids	
		Troubleshooting Guides	5-1
		Voltage Charts	6-1
		Waveforms	7-1

SAFETY NOTICE

USE ISOLATION TRANSFORMER WHEN SERVICING

Components having special safety characteristics are identified by a (Δ) on schematics and on the parts list in this Service Data and its bulletins. Before servicing this instrument, it is important that the service technician read and follow the "Safety Precautions" in the Basic Service Data.