

VOLTAGE CHARTS

CAPSTAN STATOR
CIRCUIT

MODE PIN NO.	REC	PLAY	MODE PIN NO.	STOP	FF	REW
IC2501			IC2501			
1	13.0	13.0	1	13.0	13.0	13.0
2	13.0	13.0	2	13.0	13.0	13.0
3	13.5	13.5	3	13.5	13.5	13.5
4	1.2	1.2	4	1.2	1.2	1.2
5	1.2	1.2	5	1.2	1.2	1.2
6	1.2	1.2	6	1.2	1.2	1.2
7	0.1	2.7	7	0.1	0.1	0.1
8	0	0	8	0	0	0
9	2.6	2.6	9	2.6	2.6	2.6
10	1.5	1.5	10	1.5	1.5	1.5
11	2.6	2.6	11	2.6	2.6	2.6
12	0.5	0.5	12	0.5	0.5	0.5
13	3.9	3.9	13	3.9	3.9	3.9
14	3.9	3.9	14	3.9	3.9	3.9
15	0	0	15	0	0	0
16	0	0	16	0	0	0
17	---	---	17	---	---	---
18	13.5	13.5	18	13.5	13.5	13.5
19	2.8	2.8	19	2.8	2.8	2.8
20	0	0.7	20	0	0	0
21	2.8	2.8	21	2.8	2.8	2.8
22	0	0.7	22	0	0	0
23	0.2	1.4	23	0.2	0.2	0.2
24	0	0	24	1.8	0	0
25	0	0	25	1.8	0	0
26	13.5	13.5	26	13.5	13.5	13.5
27	---	---	27	---	---	---
28	5.1	5.1	28	5.2	5.2	5.2