

TOSHIBA AMERICA CONSUMER PRODUCTS, INC.

TOSHIBA	VCR / CAMERA / LD SERVICE BULLETIN NO:77
DATE: SEPT 1994	MODELS: M750J
SUBJECT: The cassette is ejected immediately after being loaded.	

Symptom: The cassette is ejected immediately after being loaded into the VCR. This is caused by the lock release lever being out of position.

Corrective

Action: Replace the existing cassette holder assembly with the improved type listed in the table below.

Location	Part No.	Description	Quantity
K490	70324886	Holder Assembly, CAS	1