

| | | |
|---------------------|---|--|
| 1995 | TOSHIBA <i>Consumer Products</i> | <i>Date: MAR 95</i> |
| | TECHNICAL BULLETIN | No. VCR9503 |
| Product: VCR | | Models: M-650,650C,660,660C,750,750C,760,760C,770 |

Subject: Cassette not loading and/or staying in. **Ref.# 11A-9407**

Symptom: Cassette enters but is ejected due to the lock release lever, of the Cassette holder assembly, falling off.

| Required part(s): | Location | Part No. | Description |
|--------------------------|----------|----------|-------------------|
| | K490 | 70031431 | Holder Ass'y, CAS |

Corrective Action: 1) Replace the cassette holder assembly with new type. (see fig. below)

