

1995	TOSHIBA Consumer Products	Date: MAR 95
	TECHNICAL BULLETIN	No. VCR9504
Product: VCR		Models: M-750J, M-760J

Subject: Cassette not loading and/or staying in. **Ref.#** 10A-9406
SVI-238Y

Symptom: Cassette enters but is ejected due to the lock release lever, of the Cassette holder assembly, falling off.

Required part(s):	Location	Part No.	Description
	K490	70324886	Holder Ass'y, CAS

Corrective Action: 1) Replace the cassette holder assembly with new type. (see fig. below)

