


Power/CRT/Filter Schematic Diagram


NOTE:
1. DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING. THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.
2. TO MAINTAIN ORIGINAL FUNCTION AND RELIABILITY OF REPAIRED UNITS, ONLY USE ORIGINAL REPLACEMENT PARTS WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THE SERVICE MANUAL.

TEST POINT INFORMATION
○ INDICATION OF TEST POINT WITH A JUMPER WIRE ACROSS A HOLE IN P.C.B.
□ USED FOR THE INDICATION OF TEST POINT WITH COMPONENT LEAD ON FOIL SIDE.
● USED FOR THE INDICATION OF TEST POINT WITH NO TEST PIN.
● USED FOR THE INDICATION OF TEST POINT WITH TEST PIN.

NOTE: MARK "●" IS LEADLESS(CHIP) COMPONENT.



NOTE OF WIRE CONNECTORS:
1. PREFIX SYMBOL "CN" MEANS CONNECTOR.
(CAN DISCONNECT AND RECONNECT.)
2. PREFIX SYMBOL "CL" MEANS WIRE-SOLDER HOLES OF P.C.B.
(WIRE IS SOLDERED DIRECTLY.)



POWER SUPPLY C.B.A.

| Ref.No. | Position |
|-------------|----------|
| IC1001 | A-3 |
| IC1002 | E-1 |
| IC1003 | G-4 |
| IC1004 | G-3 |
| IC1005 | F-1 |
| IC9501 | A-5 |
| TRANSISTORS | |
| Q1001 | C-3 |
| Q1002 | A-3 |
| Q1003 | G-2 |
| Q1004 | G-1 |
| Q1005 | F-1 |
| Q1006 | G-2 |
| Q1007 | D-2 |
| Q9501 | C-5 |
| Q9502 | D-5 |
| TEST POINT | |
| TP1001 | G-2 |
| TP1002 | C-2 |
| TP9501 | G-5 |
| TP9502 | G-5 |
| CONNECTORS | |
| CL1001 | B-1 |
| CL9501 | H-4 |
| CN1001 | A-2 |
| CN1002 | K-2 |
| CN1003 | K-1 |
| CN9501 | H-5 |
| CN9901 | I-1 |
| VARIABLES | |
| VR1001 | F-1 |
| VR9501 | B-4 |

CRT C.B.A.

| Ref.No. | Position |
|-------------|----------|
| TRANSISTORS | |
| Q9601 | I-3 |
| Q9602 | I-3 |
| Q9603 | I-3 |
| CONNECTORS | |
| CL9601 | K-3 |
| CL9602 | H-4 |
| CN9601 | J-4 |
| CN9602 | J-3 |
| VARIABLES | |
| VR9601 | J-3 |
| VR9602 | J-2 |
| VR9603 | I-3 |
| VR9604 | I-3 |
| VR9605 | I-2 |